SEIKO


DIGITAL QUARTZ


Cal. A829A

PARTS CATALOGUE

Cal. A829A









☆ Sanyo CR2016



Cal. A829A

Characteristics

Casing diameter :

∮ 28.0 mm

Casing diameter:

25.0 mm

Maximum height:

4.9 mm without battery

Frequency of quartz crystal oscillator: 32,768 Hz (Hz = Hertz..... Cycles per second)

Rotary switch: By turning the rotary switch bezel, each function, indicated on the dial, can be selected and changed.

Time and calendar display: Hour (12-hour indication or 24-hour indication), minute, second, date, "A" "P" mark (displayed only when the calendar is adjusted.)

when the calendar is adjusted.)

Dual time display: Dual time display enables to show the local time.

Alarm display: Can be set to operate at any desired hour and minute every day (Daily alarm) and once at the time set (Single alarm) Timer display: Can be set to operate at any desired minute up to 100 minutes.

Counter display: Counter display enable to count the number up to 9999 (Single counter) and up to each 99 (Twin counter). Stopwatch display system showing minutes, second and 1/100 second up to 20 minutes.

And after 20 minutes, hours, minutes and seconds up to 12 hours.

Time signal: Can be set to ring every hour on the hour.

Display medium: Nematic Liquid Crystal, FE-Mode.

Regulation system: Trimmer condenser.
Illuminating light: Illuminates all the digital displays in the dark by depressing the light button.

PART NO.	PART NAME	PART NO.	PART NAME
4001 243 4225 245 4245 245 4245 246 4246 022 4270 245 4313 245 4398 267 4510 165 4530 200 012 178 012 178 017 648 017 648 ☆ Sanyo CR2016 ☆ National BR2016 ☆ Maxell CR2016	Circuit block Battery clamp Switch spring (A) Switch spring (B) Speaker lead terminal Battery connection (—) Connector Battery guard Liquid crystal panel frame Liquid crystal panel Reflecting mirror Bulb Battery guard screw Battery clamp screw Tube for battery guard screw Tube for battery clamp screw Lithium battery		

Remarks:

Battery

☆Sanyo CR2016

The substitutive battery might be added to the applied battery in the future.

☆ National BR2016In that case, please refer to separate "BATTERY LIST FOR SEIKO

☆ Maxell CR2016


QUARTZ WATCHES".

TECHNICAL GUIDE

SEIKO DIGITAL QUARTZ

CAL. A829A






CONTENTS

I.	SPECIFICATIONS	1
II.	STRUCTURE OF CIRCUIT BLOCK	1
III.	DISPLAY FUNCTION	2
IV.	DISASSEMBLING, REASSEMBLING AND LUBRICATING OF THE CASE	3
V.	DISASSEMBLING AND REASSEMBLING OF THE MODULE	5
VI.	CHECKING AND ADJUSTMENT	7
	Check battery voltage	7
	Check battery conductivity	7
	Check all the segments lit up	7
	Check current consumption	7
	Check water resistance	8
	• Check contact of C-MOS-LSI ~ liquid crystal panel	8
	Check liquid crystal panel and circuit block	8
	• Check accuracy	9
	Check functioning and adjusting	9
	Check alarm test system	9
	Check conductivity of switch components	9
	Check alarm condition	10
,	Check bulb condition	10

I. SPECIFICATIONS

Nematic liquid crystal, FEM (Field Effect Mode)		
 Time and calendar display (12 or 24-hour indication) Single alarm display Daily alarm display Dual time display Stopwatch display Counter function Timer display 		
Loss/gain at normal temperature range Monthly rate: lass than 15 seconds		
lock sides) ock sides)		
····		
Trimmer condenser		
Any gate is available.		
Lithium battery Sanyo CR2016, Maxell CR2016, Matsushita BR2016 Battery life is approximately 3 years. Voltage: 3.0 V		

II. STRUCTURE OF CIRCUIT BLOCK



III. DISPLAY FUNCTION

Check to see if the upper display changes as shown below by turning the rotating ring clockwise to match up each mode selection word or phrase to the mode mark "A".

Time and calendar display

 Engagement and disengagement of the hourly time signal/Activating the alarm test system.
 Depress buttons "A" and "B" at the same time,



Single alarm display Daily alarm display

Engagement and disengagement of the alarm.
 Depress button "B" in the alarm display.



Dual time display



Stopwatch display

Reset of the stopwatch.
 Depress button "B" after "STOP" appears on the panel.



Counter display

(1) Depress only button "A" to count when it is used as the single counter.



- (2) Depress buttons "A" and "B" respectively to count when it is used as the twin counter.
- Reset of the counter,
 Depress buttons "A" and "B" at the same time.




Timer display

Disengagement of the timer.
 Depress button "B" after "STOP" appears on the panel.



Time set display




IV. DISASSEMBLING, REASSEMBLING AND LUBRICATING OF THE CASE

Disassembling procedures: ① → ① Lubricating Type of oil Oil quantity

Reassembling procedures: ① → ① Silicone grease 500,000 c.s.


1) Case back ~ 6) Button 1 Case back When setting the case back -(1) Case back to the middle, use the inserting and supporting disk. (Piezoelectric element) (2) Case back gasket How to reassemble the module to the middle 1) Turn the rotating ring and set the mode selection word "COUNTER" to mode mark "A" 2 Set the transmission pins to (3) Module the inside of the middle and push them by tweezers. *Out of four transmission pins, the two positioned side by side are projecting. -(4) Transmission pin (4 pcs.) 3) Set the module to the middle. Note: If the rotating ring is not set in the above designated manner, 3 transmission pins protrude and make it difficult to set the module. Button spring clip (2 pcs.) **Button** (2 pcs.)




V. DISASSEMBLING AND REASSEMBLING OF THE MODULE

Disassembling procedures: ① → ②

Reassembling procedures: ② → ①







VI. CHECKING AND ADJUSTMENT

The explanation here is only for the particular points of Cal. A829A.

Refer to the "TECHNICAL GUIDE, GENERAL INSTRUCTION" for SEIKO Digital Quartz for ordinary checking and adjustment.

Procedure

Remarks for replacing the battery

In this calibre after replacing battery, turn the rotating ring two clicks (90° degrees) with buttons "A" and "B" depressed to reset the circuit. (Turning direction is not specified.)

And follow the same procedures after checking battery voltage.

CHECK BATTERY VOLTAGE

Set up the volt-ohm-meter

Result:

Range to be used: DC 6V

Normal: More than 3.0V Defective: Less than 3.0V

Note:

After checking battery voltage, turn the rotating ring two clicks (90° degrees) with buttons "A" and "B" depressed. (Turning direction is not specified.)

CHECK BATTERY CONDUCTIVITY

CHECK ALL THE SEGMENTS LIT UP


In the time and calendar display depress button "A" continuously for 4 to 5 seconds, and all the segments light up.

Depress button either A or B to return to the time and calendar display.

CHECK CURRENT CONSUMPTION

Set up the volt-ohm-meter

Range to be used: DC 12 μ A



Result:

Normal: Less than 1.5 μ A

Defective: More than 1,5μA


* Replace the circuit block or the liquid crystal panel.

Probe red: Battery connection (--)

Clip (+) (metal bar): Battery guard screw (Near speaker lead terminal)

Procedure

*How to find defects when the current consumption is more than 1.5 μ A. Measure the current consumption of the circuit block alone.



Result:

Normal: Less than 1.0µA

Replace the liquid crystal panel with a

new one.

Defective: More than 1.0µA

Replace the circuit

block with a new one.

CHECK WATER RESISTANCE

CHECK CONTACT OF C-MOS-LSI ~ LIQUID CRYSTAL PANEL

Refer to "Relation between the segment and C-MOS-LSI output terminal" and check for poor conductivity of the liquid crystal panel, connector and C-MOS-LSI output terminal.

CHECK LIQUID CRYSTAL PANEL AND CIRCUIT BLOCK


(1) Check to see if there are any broken wire, short circuit, etc. in the liquid crystal panel.

Set up the volt-ohm-meter

Range to be used: OHMS x 1 \sim x 1K

(2) Check to see if the electric signal is transmitted correctly from the circuit block.

Set up the volt-ohm-meter Range to be used: DC 3V



Result:

Normal : Lights up.

Defective: Does not light up.

Replace the liquid crystal panel with a

new one.

Result:

Normal : More than 0.8 V

Defective: Less than 0.8 V

Replace the circuit

block with a new one.

Procedure

CHECK ACCURACY

The daily rate can be easily measured if all the segments are lit.

* In the time and calendar display depress button "A" continuously for 4 to 5 seconds, and all segments light up. Depress button "A" or "B" to return to the normal display.

Result:

Normal: Neither gain nor loss.

Defective: Either gain or loss. Proceed to Time ac-

> curacy adjusting. *Turn the trimmer con-

denser.

CHECK FUNCTIONING AND ADJUSTING

Check to see if the time and calendar setting and other functions are normal by referring to "DISPLAY FUNCTION" on page 2.

Result:

Normal: Operate correctly.

Defective: Do not operate cor-

rectly.

CHECK ALARM TEST SYSTEM

In the time and calendar display depress buttons "A" and "B" at the same time.

Result:

Normal: The alarm rings.

-The display disappears. Replace the battery

Defective-


with a new one. LThe alarm does not ring.

Check the alarm condi-

tion.

CHECK CONDUCTIVITY OF SWITCH COMPONENTS

Check to see if the switch components (←) operate correctly.



*Also check to see if the contact points of switch spring B (touch the circuit block in fully assembled module.

Result:

Normal: Operate correctly.

Defective: Do not operate correctly.


Procedure

CHECK ALARM CONDITION

Check it when the alarm does not ring.

(1) Check for output voltage.

After applying the probes as shown in the illustration below, depress buttons "A" and "B" at the same time in the time and calendar display.



Set up the volt-ohm-meter Range to be used: DC 12µA Probe red: Battery clamp Probe black:

Speaker lead terminal

Result:

Normal: The pointer swings. Defective: The pointer does not

swing.

Check the upconverter

coil.


[Remarks for measurement]

Be careful not to get the module come up. When the module comes up, it cannot be checked correctly.

(2) Check for upconverter coil.

Volt-ohm-meter

Range to be used: OHMS x 1



Result:

Normal: $70\Omega \cdot 90\Omega$

Less than 70 Ω

(Short circuit) Defective--More than 90Ω

(Broken wire)

Replace the circuit

block.

*When there is no defect to be found through the checking procedures above, check the piezoelectric element for break, crack, etc.

CHECK BULB CONDITION